

To Set PowerPlus™ Convection in Microwave



- 1. Press CONV COOK and the display will read PREHEAT
- 2. Press OK/START. The display will read 325°. Select your desired convection temperature from 100° to 450° on the keypad.

When preheat temperature is reached, the display will read OVEN READY



FOR GREAT RECIPES USING THIS FEATURE VISIT, HTTP://WWW.FRIGIDAIRE.COM/COLLECTIONS/HOW-TO-SET-MICROWAVE-CONVECTION